



Always use appropriate Personal Protective Equipment as stated on the label or SDS.

GETTING STARTED



Step 1:

- Create a temporary blockade by utilizing appropriate signage and/or precautionary measures.
- Remove any movable objects from the area
- Apply painters tape to protect the surfaces you do not want the finish to come in contact with.

Step 3:



- Use a mop specifically designated for finish application.



Step 4:

- **Completely remove the existing finish using SC Johnson Professional Hyper-Concentrate Floor Stripper according to label instructions.**

Step 5:



- Insert a clean, unused trash can liner in the mop bucket or flat mop system.
- Fill with enough SC Johnson Professional Multi-Surface Floor Finish Plus Sealer to cover the entire work area.

Step 6:



- Rinse and completely wring dry a rayon, rayon-blend mop head or Flat Mop Applicator Pad to remove any LINT that could be transferred to the finish.
- **Note:** Always follow the Flat Mop System manufacturer's guidelines for applying floor finish.



**Use SC Johnson Professional
Multi-surface Floor Finish
Plus Sealer**

APPLYING FINISH



Step 1:

- For even coverage, lightly tamp the mop head in the wringer and hold above the bucket 2-3 seconds or until excess finish no longer drips off the mop head.



Step 2:

- Plan your application.
- Apply the finish by outlining the perimeter of the work area.



Step 3:

- Fill in the interior using an overlapping figure 8 motion with the mop head or applicator.



For even coverage, flip the mop head halfway through each section. Clean any accidental spills right away.



Step 4:

- Apply additional coats until the floor meets the desired level of appearance,
- Allow the floor to dry 30-45 minutes between coats.

There is no need to burnish the floor in between coats.

For best results, do not apply more than 4 coats in a 24 hour period.



Step 5:

- Once the finish is **dry to the touch**, a fan may be used to reduce drying time.

COMPLETING THE TASK



Step 1:

- Discard the trash can liner and any unused finish.
- Do not store finish in the mop bucket.
- Do not return unused finish to the container.



Step 2:

- Thoroughly Rinse all tools, mops and applicators

Step 3:

- After the floor is completely dry, remove the blockades and return the area to service.

Allow 24 hours before burnishing.

