

STEP 3 - REMOVING THE EZ CARE FLOOR COATING WITH EZ CARE FLOOR COATING REMOVER



GETTING STARTED



- Step 1:**
- Place proper blockades. Floors will be slippery when wet or contaminated with foreign materials or debris.
 - Gather all equipment.
 - Vacuum and remove all the matting and other objects in the entryway and outside the work area.



- Step 2:**
- Use a clean dust mop to remove any loose surface debris.
 - Use a scraper to remove any gum or foreign objects stuck to the floor.

STRING MOP APPLICATION



- Step 1:**
- Prepare the EZ Care Floor Coating Remover.
 - INSERT** the cartridge into the TruFill® Device.
 - CONNECT** the hose to the TruFill® Device.
 - TURN ON** cold water to fill mop bucket.



- Step 2:**
- Apply liberal amounts of remover solution to floor and let dwell for 10 minutes.
 - Ensure remover solution does not dry.



- Step 3:**
- Install proper pad to swing machine.**
 - AFTER INITIAL 10 MIN DWELL**, re-wet as necessary and **LET DWELL 5 MIN PRIOR TO SCRUBBING**.
 - On first pass, scrub floor with swing machine without picking up remover solution.
 - On second pass scrub floor.
 - Pick up remover solution with wet/dry vac.
 - REPEAT** steps 2-3 if necessary.



- Step 4:**
- Rinse floor with clean water. Allow floor to completely dry before applying SC Johnson Professional® EZ CARE Floor Coating.



SC Johnson Professional® EZ Care Floor Coating Remover

AUTOMATIC SCRUBBER MACHINE



- Step 1:**
- Install proper pad to auto scrubber.
 - Prepare the EZ Care Floor Coating Remover.
 - INSERT** the cartridge into the TruFill® Device.
 - CONNECT** the hose to the TruFill® Device.
 - TURN ON** cold water to fill mop bucket or automatic scrub machine.

- Step 2:**
- Apply liberal amounts of remover solution to floor while scrubbing. Let dwell for 10 minutes.
 - Ensure remover solution does not dry.



- Step 3:**
- AFTER INITIAL 10 MIN DWELL**, re-wet as necessary and **LET DWELL 5 MIN PRIOR TO SCRUBBING**.
 - On first pass, scrub floor without picking up remover solution.
 - On second pass, scrub floor while picking up remover solution.
 - REPEAT** steps 2-3 if necessary.



- Step 4:**
- Empty clean water tank with remover solution and thoroughly rinse.
 - Empty dirty water tank.
 - Fill clean water tank with water for rinsing.
 - Rinse floor with auto scrubber.
 - Rinse floor with clean water using mop and bucket.

- Step 5:**
- Allow floor to completely dry before applying SC Johnson Professional® EZ CARE Floor Coating.

COMPLETING THE TASK



- Step 1:**
- Thoroughly clean mop heads.
 - Rinse scrubbing pads and hang to dry.



- Step 2:**
- Empty out dirty water from bucket.
 - For auto scrubber –
 - Empty any remaining leftover solution in the clean water reservoir.
 - Rinse clean water reservoir.
 - Remove and wipe down the squeegee.



- Step 3:**
- Dispose of any unused remover according to the label instructions.

When the floor is dry, it is ready to be prepped with the EZ Care High Speed Conditioning and Polish Pad and finished with EZ CARE FLOOR COATING.

